

|C|D|A|

(Extractor)
(CST6/1)

Users Operating Instructions

Before operating this appliance,
please read these instructions carefully

Guarantee

CDA appliance carry a five-year parts and one-year labour guarantee.

CDA will repair or replace any defect or part attributable to faulty material or workmanship. Within the first year this will be free of both labour and parts charges. After the first year and within five years, the parts will be supplied free of charge provided that the repair is carried out by an agent authorised by CDA and the labour will be charged at the commercial rate applicable at the time of repair.

The appliance must have been installed by a suitably qualified person and in accordance with the manufacturers instructions and current legislation. The guarantee does not cover faults caused by the incorrect fitting of the appliance.

Limit of Cover

- The guarantee does not cover cosmetic damages e.g. discolouration or oxidation.
- Proof of purchase or installation date must be produced before a service call will be booked.
- The appliance must be used for domestic purposes only. Appliances used for commercial or professional purposes are not covered by this guarantee.
- The appliance must not be modified or tampered with or repair attempted by any unauthorised person.
- The guarantee does not cover damage caused by transit or by misuse, accident, abuse or neglect.
- The guarantee does not cover routine maintenance.
- Use of parts not supplied or recommended by CDA will invalidate the warranty.
- Rubber seals, filters, removable glass parts, control knobs and buttons, fuses and light bulbs which need replacing periodically are not covered by the guarantee.
- Second hand or reconditioned appliances are not covered by the guarantee.

The conditions under which this guarantee is offered are in addition to the statutory rights of the domestic purchaser and these rights are not affected by this guarantee.

CDA reserve the right to change specification without prior notice.

Appliance servicing

CDA provide a quality and effective after-sales service to cover all your servicing needs.

Please attach your receipt to this page for safekeeping.

Please help us to help you by having the following information available when booking a service call.

1. Model type, make and model – see the front of this manual
2. Evidence of installation/purchase date
3. Retailer where the appliance was purchased
4. Clear and concise details of the fault
5. Full address including postcode and any contact phone numbers

Contact telephone numbers

CDA Customer Care Department
The CDA Group Ltd
Harby Road
Langar
Nottingham
NG13 9HY

Telephone: 01949 862000
Fax: 01949 862003
Email: service@cda-europe.com

The logo consists of the letters 'C', 'D', and 'A' in a bold, serif font. Each letter is enclosed within a vertical rectangular frame, and the frames are separated by small gaps.

INSTALLATION

The appliance has been designed as exhausting hood (external exhausting) or filtering one (internal recirculation).

The appliance has to be installed at a minimum height of 650 mm. above the electric cookers or 750 mm. above the gas or mixed ones. Do not connect the discharge pipe to a flue in which warm air circulates or which is used to remove fumes of the appliances which are powered with a different energy from the electric one. Pay attention if an exhausting hood and a burner or a fireplace depending on the air of the room and which are powered with a different energy from the electric one work at the same time, because during the aspiration the hood takes the air away from the room, that air which is necessary to the burner or the fireplace for the combustion. So for a safe working, provide for a proper ventilation of the room. For the external exhausting, conform to the laws in force in your country.

The appliance must be placed in such a way, that the supply plug is accessible.

ELECTRICAL CONNECTION

The appliance is built in class II, so no wire has to be connected with the earth terminal.

The connection to the electrical mains must be made as follows:

Brown = L live

Blu = N neutral

If is not supplied, fit a plug normalized on the cord for the load showed on the rating plate. In the case of a direct connection to the mains, it is necessary to place between the appliance and the mains an-omnipolar switch minimum opening between contacts of 3 mm. dimensioned for the load and corresponding with the laws in force.

ATTENTION: should the lamps not work, make sure they are well tightened.

MOUNTING OF THE HOOD IN THE LOWER PART OF AN HANGING CUPBOARD

Drill 4 holes of 6 mm. diameter at the bottom of the hanging cupboard as showed in the drawing fig. 1.

Fill the hood in the cabinet with 4 screws, which are appropriate to that kind of cupboard.

The appliance is provided with 2 air outlets, one which is in the upper part and the other on the back. Both of them can be used according to your requirements.

A connecting ring (C), which to join the connecting pipe to, and a cover (A) to close the air outlet, which is not used, are supplied.

MOUNTING OF THE HOOD ON THE WALL

Drill 2 holes on the wall, which correspond to the position (B) of the drawing fig. 1.

Hang the hood on the 2 holes by using the screws and doweis with expanding plug, which are appropriate for that kind of wall (ex.: concrete, plaster-board, etc.).

Fix definitely the hood through the 2 security holes (Z).

CHANGING FROM EXHAUSTING HOOD TO THE FILTERING ONE

In order to make this change (possible also after the use of the exhausting system), demand a set of carbon filters to your dealer. Active carbon filters are necessary to depurate the air, that will be released in the room. Filters are not washable: they cannot be regenerated and have to be replaced at most every 4 months. The saturation of the activated charcoal depends on the more or less prolonged use of the hood, on the type of cooking and on the regularity of cleaning the grease filter. The filter (C) has to be applied to the aspirating group, which is inside the hood hitin the centre of the group with it and turning it of 90 degrees until the stop click is heard to lock it. Remove the grill (G) to carry out this operation. Close with the appropriate covers the upper and back air outlets; turn the small lever (L) from the position (A) to the position (F). In this way the hood is ready for the filtering function.

USE AND MAINTENANCE

It is advisable to let the appliance work for 15 minutes after the cooking of the food in order to remove completely the fumes. In the frontal part of the appliance there are an on/off switch for the light, and a switch to change the working speeds. The effective functioning of the hood depends on the regularity with which the maintenance operations are carried out, in particular those of the anti-grease filter.

The anti-grease filter, which rests on the grill, has the function of catching the particules suspended on the air, so it is subject to get clogged at various intervals, according to the use of the appliance.

In any case at most after two months, it is necessary to clean the filter by doing the following operations:

- Remove the filter from the grill and wash it with a solution of water and neutral liquid detergent, allowing the dirt to soften;
- rinse thoroughly with lukewarm water, allow to dry without twisting and apply it to the grill.

If the appliance is provided with a metal filter, it can be washed also in the dishwasher, dried and reapplied to the grill.

In case the washing instructions of the filter should not be followed, it could burst into flames.

Clean frequently all the deposits on the fan and on all the other surfaces, using a cloth moistened by methylated spirits or neutral and not abrasive fluid detersive.

WARNING!!

UNDER CERTAIN CIRCUMSTANCES DOMESTIC APPLIANCES MAY BE DANGEROUS.

- Do not check filters with hood working.
- Do not touch the lamps after a prolonged use of the appliance.
- No food must be cooked flambe underneath the hood.
- The use of an unprotected flame is dangerous for the filters and could cause fires.
- Watch constantly the fried food in order to avoid that the cooking oil flares up.
- Before performing any maintenance operation, disconnect the hood from the mains.

The Manufacturers refuse to accept any responsibility for eventual damages, because of failure to observe the above instructions.

This appliance complies with the directions EMC 89/336/EEC revised 92/31/EEC and 93/68/EEC.

When the power supply cord is damaged it must be replaced by an official dealer.